

Touchscreen Secondary Keypad



DO NOT PLUG INTO WALL BEFORE
MAIN CONTROL PANEL IS PLUGGED IN!

- 1 Locate the area where you want the remote keypad.
- 2 Plug it in (not on a switched outlet or one with a test/reset button).

