


Garage Door Tilt Sensor



- 1 Remove the sensor cover from sensor base.
- 2 Secure the sensor base to the top of the interior of the garage door with the provided screws (recommended).
 - » The higher the placement on the door, the better.
 - » Screws are the most secure way of attaching the unit, but be careful not to damage the door when installing.
 - » Be sure to secure the top of the sensor base towards the ceiling.
- 3 After securing the sensor base to the garage door, snap the sensor cover to the base.