




Wireless Doorbell



Drain hole



- 1 To remove the sensor cover, use your finger to press the tab. This disengages the clip holding the cover to the base.
 - » If possible, locate the sensors within 100 feet of the panel.
 - » Avoid mounting it in areas where it will be exposed to extreme moisture.
 - » If connecting to existing doorbell wiring, see optional instructions before proceeding.
- 2 Mount the doorbell using the orientation shown. Use the provided Phillips wood screws to attach the base to the mounting surface. Make sure the arrows are pointed up (as shown).
- 3 Place the provided O-ring around the perimeter of the base.
- 4 Pull the battery tab out and discard tab.
- 5 Replace the sensor cover. Make sure the drain hole is facing down. If the cover does not snap in place, it may be upside down.

OPTIONAL: CONNECT EXISTING 24V WIRING

- » Pull the existing house 24 AC wiring through the hole and attach to the board using the machine screws provided.
- » If this step is skipped, the doorbell will work only with the control panel and the LED will not illuminate.